

## Intake Manifold - TGV


NOTE:

Always use new gaskets.

**Tightening torque:**

**8.25 N·m (0.84 kgf·m, 6.1 ft·lb)**

Gaskets



Intake Collector = 14075AA161


## TGV - Head (s)

NOTE:

Always use new gaskets.

**Tightening torque:**

**25 N·m (2.5 kgf·m, 18.1 ft·lb)**



Intake Manifold = 14035AA421